

Seater Head 10,57/.416-R123

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,57/.416-R123](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017544
- Mfr. No.: 3000054V-10.57-R123
- Diameter (in): 0.416
- Diameter mm: 10,57
- Radius: R123
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.57-R123

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,57/.416R123. This product is designed for precise and gentle bullet seating, ensuring optimal performance and accuracy in your reloading process. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as specified by the manufacturer.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Follow all local laws and regulations regarding the use and handling of reloading equipment.
- In case of any malfunction or defect, stop using the product immediately and consult with a qualified professional.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE), including safety glasses and gloves, when handling reloading equipment.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge to ensure safety and effectiveness.
- Ensure that the workspace is clean and free from distractions while using the Seater Head.
- Avoid using excessive force during operation to prevent damage to the product and ensure safety.
- Do not attempt to modify or repair the Seater Head. Consult a professional for any necessary repairs.

Instructions for Installation and Usage

1. Selecting the Correct Seater Head

- Use the tool available on the manufacturer's website (www.triebelreloading.com) to select the correct seater head for your application.

2. Installation

- Ensure that your reloading press is turned off and unplugged before starting the installation.
- Remove any existing seater head from the die.
- Carefully insert the Seater Head into the die, ensuring it is properly secured.
- Tighten the die according to the manufacturer's specifications.

3. Usage

- Prepare your cartridges according to standard reloading practices.
- Place the bullet into the case mouth.
- Using the reloading press, apply gentle pressure to seat the bullet with the Seater Head.
- Monitor the alignment of the bullet to ensure proper seating.

4. PostUsage Care

- After use, clean the Seater Head to remove any debris or residues.
- Store the Seater Head in a safe and dry location, away from moisture and extreme temperatures.

Disposal Instructions

- Dispose of the Seater Head in accordance with local waste management regulations.
- Do not dispose of the product in general household waste if it is damaged or defective.
- Check with local authorities for proper disposal methods for reloading equipment and materials.

Contact Information for Further Support

For any inquiries regarding safety or product usage, please consult the manufacturer's website or contact their support team directly.

By following these guidelines, you can ensure safe and effective use of the Seater Head 10,57/.416R123, enhancing your reloading experience while adhering to safety regulations. Thank you for your attention to these important safety instructions.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk