

Seater Head 10,75/.423-R16

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 10,75/.423-R16](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017548
- Mfr. No.: 3000054V-10.75-R016
- Diameter (in): 0.423
- Diameter mm: 10,75
- Radius: R16
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-10.75-R016

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 10,75/.423R16 from TRIEBEL. This guide provides essential safety instructions to ensure the safe use and maintenance of your product. Please read this guide carefully before using the product.

General Safety Guidelines

- Always follow the manufacturer's instructions for use and maintenance.
- Ensure that the product is used only for its intended purpose, which is bullet seating.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe product conditions or accidents to the appropriate authorities.
- Check for any recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Improper use may lead to inaccurate bullet seating, which can affect firearm performance and safety.
- Risk of injury if the product is mishandled or used incorrectly.

- **Avoiding Hazards:**

- Always ensure that the seater head is securely attached to the reloading die before use.
- Do not force the bullet into the case; use smooth, consistent pressure.
- Use protective eyewear when reloading to safeguard against any potential debris or accidents.
- Ensure that your workspace is clean and free of clutter to prevent accidents.

- **AgeSpecific Warnings:**

- This product is not intended for use by individuals under the age of 18 without adult supervision.
- Ensure that inexperienced users are guided by knowledgeable individuals when using the product.

Instructions for Installation and Usage

- **Installation:**

1. Ensure that your reloading press is clean and properly set up.
2. Select the correct seater head using the tool on the manufacturer's website: www.triebelreloading.com.
3. Carefully screw the seater head into the die until it is securely fastened.
4. Adjust the seater head to the desired depth according to your specific reloading needs.

- **Usage:**

1. Place the cartridge case in the reloading press.
2. Insert the bullet into the mouth of the cartridge case.
3. Apply gentle, consistent pressure on the press handle to seat the bullet.
4. After seating, inspect the cartridge for proper bullet alignment and depth.
5. Repeat the process for additional cartridges as needed.

Disposal Instructions

- Dispose of the product according to local regulations regarding metal waste and reloading components.
- Do not dispose of the product in regular household waste.
- Contact your local waste management facility for guidance on proper disposal methods.

Contact Information for Further Support

For any safety inquiries or further support regarding the Seater Head, please refer to the manufacturer's website or contact their support team directly. Ensure you have your product details on hand for a more efficient response.

By following these guidelines, you can ensure a safer and more effective reloading experience with your Seater Head 10,75/.423R16. Thank you for prioritizing safety in your reloading activities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk