

Seater Head 11,05/.435-R65

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 11,05/.435-R65
- Manufacturer: TRIEBEL
- Product no.: EU2017551
- Mfr. No.: 3000054V-11.05-R065
- Diameter (in): 0.435
- Diameter mm: 11,05
- Radius: R65
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-11.05-R065

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instructions](#)

Seater Head Safety Instructions

Introduction

Thank you for choosing the Seater Head 11,05/.435R65. This product is designed for precision bullet seating and is made from highquality brass. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always ensure that the Seater Head is compatible with your reloading equipment.
- Use the Seater Head only for its intended purpose to avoid accidents.
- Keep the Seater Head out of reach of children and unauthorized users.
- Regularly inspect the Seater Head for any wear or damage before use.
- Report any unsafe conditions or incidents to the appropriate authorities.
- Stay informed about product recalls and safety notices through the EU Safety Gate platform.

Specific Safety Precautions for Use

- **Hazard Identification:**

- Improper use may result in injury or damage to equipment.
- Ensure that you are familiar with reloading practices before using this product.

- **Avoiding Hazards:**

- Always wear appropriate safety gear, including safety glasses and gloves.
- Make sure your workspace is clean and free from distractions.
- Do not exceed the recommended specifications for bullet seating.
- Use the Seater Head in a wellventilated area to avoid inhaling any dust or particles.
- Follow all safety instructions provided with your reloading equipment.

- **AgeSpecific Warnings:**

- This product is not intended for use by individuals under the age of 18 unless supervised by a responsible adult.

Instructions for Installation and Usage

- **Installation:**

- Ensure that your reloading press is securely mounted and stable.
- Carefully follow the manufacturer's instructions for installing the Seater Head onto your reloading press.
- Tighten all connections securely to prevent movement during use.

- **Usage:**

- Adjust the Seater Head according to the specifications provided for your bullets.
- Perform a test seating with a dummy round to ensure proper alignment and function.
- Monitor the seating depth and adjust as necessary to achieve desired results.
- After usage, clean the Seater Head to remove any residue or debris.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the Seater Head is damaged or no longer usable, contact your local waste management facility for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact their support team. Always ensure you have the product details available for efficient assistance.

Thank you for following these safety instructions. Your safety and satisfaction are our top priorities.