

Seater Head 11,60/.458-R60

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 11,60/.458-R60
- Manufacturer: TRIEBEL
- Product no.: EU2017556
- Mfr. No.: 3000054V-11.60-R060
- Diameter (in): 0.458
- Diameter mm: 11,60
- Radius: R60
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-11.60-R060

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 11,60/.458R60. This product is designed for precision bullet seating and is made from highquality brass. To ensure your safety and the effective use of this product, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- **Product Safety:** This product is designed to be safe for use when handled properly. Always follow the instructions provided to minimize risks.
- **Enhanced Recalls:** In the unlikely event of a product recall, you will be notified through standardized notices. Always check for updates regarding recalls.
- **Online Shopping:** If purchased online, ensure that the seller complies with safety regulations equivalent to those of physical stores.
- **Special Consumer Focus:** Extra care should be taken if the product is used by or around vulnerable groups, including children.
- **EU Contact Point:** For any safety inquiries, look for the EUbased contact information provided by the manufacturer.
- **Rapid Alerts:** Stay informed about any unsafe products through the EU's Safety Gate system.

Specific Safety Precautions for Use

- **Proper Handling:** Always handle the seater head with care to avoid damage and ensure safe operation.
- **Protective Equipment:** Wear safety glasses and gloves when using this product to protect against potential debris and sharp edges.
- **Inspect Before Use:** Always inspect the seater head for any signs of damage or wear before use. Do not use if damaged.
- **Storage:** Store the seater head in a dry, secure location away from children and pets to prevent accidents.
- **Compatibility:** Ensure that the seater head is compatible with your reloading equipment before use.

Instructions for Installation and Usage

1. Compatibility Check:

- Confirm that the seater head is suitable for your original dies from Triebel Waffenwerkzeuge.
- Use the tool on the manufacturer's website to select the correct seater head.

2. Installation:

- Ensure your reloading press is turned off and unplugged before installation.
- Carefully remove any existing seater head from your reloading die.
- Install the Seater Head 11,60/.458R60 by screwing it into the die until securely fastened.

3. Usage:

- Set up your reloading station according to the manufacturer's guidelines.
- Load the cartridge case into the press and ensure it is properly aligned.
- Insert the bullet into the case mouth and lower the press handle to seat the bullet.
- Check the alignment and depth of the seated bullet before proceeding with further reloading steps.

4. PostUse Care:

- After use, clean the seater head to remove any residue.
- Store the seater head in a protective case or designated storage area.

Disposal Instructions

- Dispose of any damaged or unusable parts in accordance with local regulations.
- Do not dispose of the product with regular household waste. Consider recycling options if available.

Contact Information for Further Support

For any further inquiries regarding safety or product use, please refer to the contact information provided by the manufacturer on their official website. Always ensure that you are using the latest information and guidelines.

Thank you for prioritizing safety while using the Seater Head 11,60/.458R60. Your adherence to these guidelines will help ensure a safe and effective reloading experience.