

Seater Head 12,90/.500-R115

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: [Seater Head 12,90/.500-R115](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2017568
- Mfr. No.: 3000054V-12.90-R115
- Diameter (in): 0.505
- Diameter mm: 12,90
- Radius: R115
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-12.90-R115

Table of Contents

- [Startpage](#)
- [Seater Head Safety Instruction Guide](#)
- [About Us](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 12,90/.500R115. This guide provides essential safety instructions and guidelines to ensure the safe and effective use of this product. Please read the entire document carefully before use.

General Safety Guidelines

- Ensure that the Seater Head is used only with compatible dies from Triebel Waffenwerkzeuge.
- Always read and follow the manufacturer's instructions for your reloading equipment.
- Keep the product out of reach of children and vulnerable individuals.
- Do not use the Seater Head for any purpose other than its intended use.
- Regularly inspect the Seater Head for signs of wear or damage before each use.
- Report any unsafe conditions or incidents to the appropriate authorities.

Specific Safety Precautions for Use

- Wear appropriate personal protective equipment (PPE), such as safety glasses, while using the Seater Head.
- Ensure that the working area is clean and free from obstructions.
- Do not exceed recommended specifications for the Seater Head, including diameter and radius limits.
- Handle the Seater Head with care to avoid injury from sharp edges.
- Follow all local laws and regulations regarding reloading and ammunition.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure that your reloading press is clean and free from debris.
2. **Compatibility Check:** Verify that the Seater Head is compatible with your existing dies.
3. **Installation:**
 - Remove the existing seater head from your die.
 - Carefully install the Seater Head into the die, ensuring it is securely tightened.
 - Adjust the seating depth according to your specifications.

Usage

1. **Setup:**
 - Set up your reloading press according to the manufacturer's instructions.
 - Ensure that all components are properly aligned and functioning.
2. **Seating Process:**
 - Place the cartridge case into the die.
 - Insert the bullet into the case mouth.
 - Activate the press to seat the bullet using the Seater Head.
 - Check the cartridge for proper bullet seating and alignment.
3. **PostUse:**
 - After use, clean the Seater Head and surrounding area to prevent residue buildup.
 - Store the Seater Head in a safe, dry location when not in use.

Disposal Instructions

- Dispose of the Seater Head in accordance with local regulations.
- Do not dispose of the product in general waste if it is damaged or no longer usable.
- Consider recycling options if available for metal components.

Contact Information for Further Support

For any inquiries regarding safety or product usage, please refer to the manufacturer's website or contact the appropriate support channels.

By following these safety instructions and guidelines, you can ensure a safe and effective experience with your Seater Head 12,90/.500R115. Thank you for your attention to safety and compliance with the EU General Product Safety Regulation.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk