

Seater Head 17,78/.700-R18

Seater head made from high-quality brass, precision-machined in a single setup on modern CNC machines – for precise and gentle bullet seating. Profile-matched design ensures optimal axial bullet alignment, improving cartridge concentricity and overall accuracy. Select the correct seater head using the tool on the manufacturer's website www.triebel-reloading.com. Suitable for original dies from Triebel Waffenwerkzeuge.



Attributes

- Name: Seater Head 17,78/.700-R18
- Manufacturer: TRIEBEL
- Product no.: EU2017577
- Mfr. No.: 3000054V-17.78-R018
- Diameter (in): 0.700
- Diameter mm: 17,78
- Radius: R18
- Delivery weight: 0.015kg
- Shipping height: 15mm
- Shipping width: 15mm
- Shipping length: 30mm
- EAN/UPC: 3000054V-17.78-R018

Table of Contents

- [Startpage](#)
- [English: Seater Head Safety Instruction Guide](#)

Seater Head Safety Instruction Guide

Introduction

Thank you for choosing the Seater Head 17,78/.700R18. This product is designed for precision bullet seating, ensuring improved cartridge concentricity and overall accuracy. Please read this safety instruction guide carefully to ensure safe and effective use of the product in compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Always ensure that the Seater Head is used in accordance with the manufacturer's instructions.
- Inspect the product for any visible damage or defects before use.
- Keep the Seater Head out of reach of children and vulnerable individuals.
- Use the Seater Head only with compatible dies from Triebel Waffenwerkzeuge.
- Report any unsafe products or incidents to the appropriate authorities.
- Stay informed about product recalls and safety updates via the EU Safety Gate platform.

Specific Safety Precautions for Use

- **Hazard Identification:**

- The Seater Head is designed for precision use and may pose risks if not handled correctly.
- Potential hazards include improper alignment leading to inaccurate bullet seating and potential damage to the cartridge or firearm.

- **Avoiding Hazards:**

- Always ensure the Seater Head is properly aligned before use to avoid misfires or damage.
- Do not use excessive force when seating bullets, as this may compromise accuracy and safety.
- Ensure that your workspace is clean and free of distractions to prevent accidents.

- **AgeSpecific Warnings:**

- This product is not intended for use by individuals under the age of 18. Ensure that only qualified adults handle and operate this equipment.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Seater Head is compatible with your specific Triebel die.
- Securely attach the Seater Head to the reloading press according to the manufacturer's instructions.
- Verify that it is tightly fitted and stable before proceeding.

2. Usage:

- Prepare your cartridges and ensure they are clean and free from any obstructions.
- Place the bullet into the cartridge case and position it under the Seater Head.
- Slowly and steadily operate the reloading press to seat the bullet. Avoid using excessive force.
- After seating, inspect the cartridge for proper alignment and seating depth.

3. PostUsage Care:

- Clean the Seater Head after each use to maintain its precision and performance.
- Store the Seater Head in a safe, dry place when not in use.

Disposal Instructions

- Dispose of any damaged or wornout components in accordance with local regulations.
- Do not throw the Seater Head in regular household waste. Check with local authorities for proper disposal methods for metal components.

Contact Information for Further Support

For any questions or concerns regarding the Seater Head, please refer to the manufacturer's website or contact your local distributor for assistance.

Thank you for your attention to safety and proper use. Enjoy your reloading experience with the Seater Head 17,78/.700R18!