

Picatinny Risers - Picatinny-Riser, BH15 L130, lever

Secure Accessory Mounting: Engineered with a robust Picatinny-to-Picatinny profile, this flip-on mount allows for the fast, easy, and rock-solid installation of tactical accessories such as lasers, weapon lights, foregrips, and secondary devices.



Optic Sightline Elevation: Highly versatile in design, this mount doubles as a premium optic riser, allowing you to elevate your red dot sights to a more comfortable and ergonomic height for a cleaner sight picture.

Attributes

- Name: Picatinny-Riser, BH15 L130, lever
- Manufacturer: ERATAC
- Product no.: EU2018052
- Mfr. No.: T4213-0115
- Colour: Black
- Delivery weight: 0.16kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- EAN/UPC: T4213-0115

Table of Contents

- [Startpage](#)
- [English: Picatinny Risers Safety Instructions](#)

Picatinny Risers Safety Instructions

Introduction

Thank you for choosing the Picatinny Risers. This product is designed to enhance your tactical setup by providing secure accessory mounting and elevation for optic sights. To ensure safe and effective use of your Picatinny Risers, please carefully read and follow these safety instructions.

General Safety Guidelines

- Ensure that the Picatinny Risers are compatible with your firearm before installation.
- Always handle firearms and accessories with care and in accordance with local laws and regulations.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the Picatinny Risers for any signs of wear or damage before each use.
- If you notice any defects or issues, discontinue use immediately and seek assistance.

Specific Safety Precautions for Use

- Do not exceed the weight limit specified for the Picatinny Risers to avoid potential failure during use.
- Ensure that all accessories mounted on the risers are securely fastened to prevent accidents.
- Avoid using the Picatinny Risers in extreme weather conditions without proper precautions.
- Be mindful of your surroundings when using firearms equipped with accessories mounted on the Picatinny Risers.
- Always use eye and ear protection when operating firearms.

Instructions for Installation and Usage

1. Preparation:

- Ensure your firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, such as a screwdriver.

2. Installation:

- Align the Picatinny Risers with the Picatinny rail on your firearm.
- Use the provided screws to secure the risers in place. Ensure they are tightened adequately but do not overtighten, which may strip the screws or damage the risers.
- Attach your tactical accessories (lasers, weapon lights, etc.) to the Picatinny Risers according to the manufacturer's instructions for those accessories.

3. Usage:

- Once installed, verify that all components are secure before use.
- Adjust the height of your optic sights as needed for a comfortable and ergonomic shooting position.
- Regularly check the tightness of all screws and the condition of the risers during use.

Disposal Instructions

- Dispose of the Picatinny Risers in accordance with local regulations for electronic waste and materials.
- Do not dispose of the product in regular household waste.
- If unsure about disposal methods, contact your local waste management authority for guidance.

Contact Information for Further Support

For any safety inquiries or further support regarding the Picatinny Risers, please refer to the included warranty information and contact your local authorized dealer.

By following these safety instructions, you can ensure a safe and effective experience with your Picatinny Risers. Thank you for prioritizing safety and responsibility in your firearm handling.