

Bullet Feeder | Gen2 (Frankford Arsenal, .45 ACP)

New and Improved: The ABF Gen 2 builds upon the trusted foundation of our original system, introducing precision upgrades where they matter most. Packed with advanced smart features and enhanced system integration, it delivers a major leap forward in performance, reliability, and reloading efficiency.



Attributes

- Name: Armanov Bullet Feeder | Gen2 (Frankford Arsenal, .45 ACP)
- Manufacturer: ARMANOV
- Product no.: EU2018245
- Mfr. No.: ABFG2FA45
- Colour: Black
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Armanov Bullet Feeder | Gen2 Safety Instruction Guide](#)

Armanov Bullet Feeder | Gen2 Safety Instruction Guide

Introduction

Thank you for choosing the Armanov Bullet Feeder | Gen2. This guide provides essential safety instructions to ensure your safe and effective use of the product. Please read this manual carefully before installation and use.

General Safety Guidelines

- Always follow the manufacturer's instructions for safe operation.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage before use.
- Report any unsafe conditions or accidents to the relevant authorities.
- Stay informed about any product recalls or safety alerts via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Do not exceed the recommended capacity of the bullet feeder.
- Ensure that the product is securely attached to the reloading press before use.
- Avoid wearing loose clothing or jewelry while operating the bullet feeder.
- Always keep hands and other body parts clear of moving parts during operation.
- Use only compatible components with the Armanov Bullet Feeder | Gen2.
- If you experience any malfunction or irregularities, stop using the product immediately and consult the troubleshooting section of the manual.

Instructions for Installation and Usage

1. Installation:

- Unbox the Armanov Bullet Feeder | Gen2 and check for all included components.
- Follow the assembly instructions provided in the manual to properly set up the feeder.
- Attach the bullet feeder securely to your reloading press ensuring all connections are tight.

2. Usage:

- Load the feeder with the appropriate bullets as specified in the manual.
- Adjust the feeder settings according to the type of ammunition being loaded.
- Monitor the feeding process to ensure smooth operation and prevent jams.
- If a jam occurs, turn off the power and clear the obstruction before resuming use.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling components where possible to minimize environmental impact.

Contact Information for Further Support

For further inquiries or support regarding the Armanov Bullet Feeder | Gen2, please reach out to your local distributor or manufacturer. Ensure that you have the product details and any relevant information ready to

assist with your inquiry.

Thank you for prioritizing safety while using the Armanov Bullet Feeder | Gen2. Your attention to these guidelines helps ensure a safe and efficient reloading experience.