

Ball Bearing Roller Handle for Dillon XL650/XL750, RL550 and Square Deal B (Dillon Square Deal B)

Upgrade your reloading comfort and control. Replace the standard factory operating handle of your Dillon Square Deal B with this premium, ergonomic upgrade featuring a smooth-swiveling aluminum roller grip. Finished in a vibrant anodized blue, it is designed to perfectly complement your press while drastically shifting the physics of your stroke.



Attributes

- Name: Ball Bearing Roller Handle for Dillon XL650/XL750, RL550 and Square Deal B (Dillon Square Deal B)
- Manufacturer: ARMANOV
- Product no.: EU2018271
- Mfr. No.: BBDRHD-SDB
- Colour: Blue
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Ball Bearing Roller Handle for Dillon XL650/XL750, RL550, and Square Deal B](#)

Safety Instruction Guide for Ball Bearing Roller Handle for Dillon XL650/XL750, RL550, and Square Deal B

Introduction

Thank you for choosing the Ball Bearing Roller Handle for your Dillon XL650/XL750, RL550, and Square Deal B. This premium upgrade is designed to enhance your reloading comfort and control. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Always follow the manufacturer's instructions for installation and use.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product regularly for any signs of wear or damage.
- Report any unsafe conditions or accidents to the appropriate authorities.
- Stay informed about product recalls or safety alerts via the EU Safety Gate platform.

Specific Safety Precautions for Use

- Use the roller handle only when the reloading press is securely mounted and stable.
- Avoid excessive force when operating the handle to prevent strain or injury.
- Ensure that the handle is securely attached before use.
- Do not modify the handle or press in any way that could compromise safety.
- Always wear appropriate personal protective equipment (PPE) while reloading.

Instructions for Installation and Usage

Installation Instructions

1. Preparation

- Ensure that your Dillon press is turned off and unplugged.
- Gather necessary tools, including a wrench for securing screws.

2. Remove the Existing Handle

- Locate the screw or bolt securing the factory handle.
- Use the wrench to remove the screw or bolt.
- Carefully detach the factory handle from the press.

3. Install the Ball Bearing Roller Handle

- Align the new roller handle with the mounting point on the press.
- Insert the screw or bolt through the handle and into the mounting point.
- Use the wrench to securely tighten the screw or bolt, ensuring the handle is firmly attached.

4. Final Check

- Check that the handle is securely installed and does not wobble.
- Ensure that the handle moves smoothly without obstruction.

Usage Instructions

- To operate the roller handle, grip the aluminum roller grip firmly.
- Apply a smooth, even pressure as you cycle the reloading press.
- If you experience any resistance or unusual noise, stop using the press and inspect for issues.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the product reaches the end of its life, dispose of it responsibly. Consider recycling if applicable.
- Do not dispose of the product in household waste if it contains hazardous materials.

Contact Information for Further Support

For any safety inquiries or support regarding your Ball Bearing Roller Handle, please reach out to the manufacturer or authorized dealer. Always refer to the product documentation for additional information.

Thank you for your attention to these safety guidelines. Your safety is our priority, and we wish you a safe and enjoyable reloading experience.