

Mini Bullet Feeder (.223 Rem)

A cost-effective solution for enhancing efficiency and safety. The Armanov Mini Bullet Feeder automates the bullet placement process, completely eliminating the need to insert your fingers between the die and the case. While the full-scale Armanov Bullet Feeder Gen2 is an incredible high-volume upgrade, this Mini version serves as the perfect entry-level solution for those new to reloading or working with lower production volumes.



Attributes

- Name: Armanov Mini Bullet Feeder (.223 Rem)
- Manufacturer: ARMANOV
- Product no.: EU2018394
- Mfr. No.: MINIBF223
- Colour: Blue
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Armanov Mini Bullet Feeder Safety Instruction Guide](#)

Armanov Mini Bullet Feeder Safety Instruction Guide

Introduction

Thank you for choosing the Armanov Mini Bullet Feeder (.223 Rem). This product is designed to enhance the efficiency and safety of your reloading process. Please read this safety instruction guide carefully to ensure safe and effective use of the Mini Bullet Feeder.

General Safety Guidelines

- Ensure that you read and understand all instructions before using the product.
- Always use the Mini Bullet Feeder in a wellventilated area.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the Mini Bullet Feeder for any signs of wear or damage.
- Do not modify or alter the product in any way.
- Use the product only for its intended purpose as described in this guide.
- If you encounter any issues or have questions, seek assistance from a qualified professional.

Specific Safety Precautions for Use

- Avoid placing your fingers between the die and the case during operation to prevent injury.
- Ensure that the Mini Bullet Feeder is securely attached to your reloading press before use.
- Do not overload the feeder; follow the manufacturer's guidelines for capacity.
- Use only compatible bullets as specified by the manufacturer.
- Always wear appropriate safety gear, such as safety glasses, when operating the Mini Bullet Feeder.
- In case of a malfunction, stop using the product immediately and consult the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Unbox the Mini Bullet Feeder and ensure all components are included.
- Attach the feeder securely to your reloading press according to the manufacturer's instructions.
- Adjust the feeder height to ensure proper alignment with the die.
- Check that the feeder is stable and does not wobble.

2. Usage:

- Load the bullets into the feeder as per the recommended capacity.
- Start the reloading press and allow the Mini Bullet Feeder to automate the bullet placement.
- Monitor the operation to ensure that bullets are being placed correctly.
- If any bullet jams occur, stop the operation and clear the jam before proceeding.
- After completing the reloading process, turn off the reloading press and detach the Mini Bullet Feeder.

Disposal Instructions

- Dispose of the Mini Bullet Feeder in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- If the product is no longer usable, consider recycling it at a designated facility.

Contact Information for Further Support

For any inquiries regarding the safety or operation of the Armanov Mini Bullet Feeder, please reach out to the manufacturer or an authorized dealer. It is important to ensure that all safety concerns are addressed promptly.

By following these safety instructions, you can help ensure a safe and effective reloading experience with your Armanov Mini Bullet Feeder. Thank you for your attention to safety and compliance with the EU General Product Safety Regulation.