

Mini Bullet Feeder - Mirror for Hornady Case-feeder

This inspection mirror is a simple and effective solution for keeping total control over the quantity of brass inside your case feeder. Because case feeders are inherently mounted high on the press, peeking inside to check fill levels or diagnose a feeding stoppage can be a constant hassle. Instead of reaching for a chair or a step stool, this premium convex mirror provides a wide-angle view of every single corner of the feed bowl. Toolless Installation Setup takes only a few seconds and requires absolutely no tools. Simply mount it onto the straight edge of the case feeder rim and adjust the mirror angle to fit your seating position.



Attributes

- Name: Mirror for Hornady Case-feeder
- Manufacturer: ARMANOV
- Product no.: EU2018399
- Mfr. No.: MIRHCF
- Colour: Red
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Armanov Mini Bullet Feeder Mirror Safety Instruction Guide](#)

Armanov Mini Bullet Feeder Mirror Safety Instruction Guide

Introduction

Thank you for choosing the Armanov Mini Bullet Feeder Mirror for your Hornady Casefeeder. This product is designed to enhance your reloading experience by providing a clear view of the brass in your case feeder, ensuring that you can maintain control over your reloading process. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the mirror is installed securely to prevent it from falling and causing injury.
- Inspect the mirror before each use for any damage. Do not use if cracked or broken.
- Keep the mirror out of reach of children to prevent accidents.
- Do not use the mirror for any purpose other than as intended.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- Avoid placing the mirror in a location where it may obstruct your view of the reloading process.
- Do not adjust the mirror while the case feeder is in operation.
- Ensure that the mirror is adjusted to a comfortable viewing angle before starting the reloading process.
- Use caution when handling the mirror to avoid sharp edges that may cause cuts or injuries.
- If you experience any issues with the case feeder, stop using it immediately and inspect for any blockages or malfunctions.

Instructions for Installation and Usage

Installation

1. **Unpack the Mirror:** Carefully remove the mirror from its packaging.
2. **Select Mounting Location:** Identify a straight edge on the rim of your case feeder where the mirror will be mounted.
3. **Mount the Mirror:**
 - Position the mirror against the straight edge.
 - Ensure that it fits securely without any gaps.
4. **Adjust the Angle:**
 - Tilt the mirror to achieve a wideangle view that allows you to see the entire feed bowl.
 - Make sure the mirror is stable and does not move during operation.

Usage

- Before starting your reloading process, check the mirror's position to ensure it provides a clear view.
- During operation, glance at the mirror to monitor the fill level of brass in the case feeder.
- If you notice any feeding stoppages, use the mirror to diagnose the issue without needing to climb or reach excessively.

Disposal Instructions

- Dispose of the mirror in accordance with local regulations for plastic and glass waste.
- If the mirror is damaged, wrap it securely to prevent injury and take it to a designated waste disposal facility.

Contact Information for Further Support

For any safety inquiries or assistance regarding the Armanov Mini Bullet Feeder Mirror, please refer to the product packaging or visit the manufacturer's website for more information.