

Retaining Clip for Dillon 1050 / 1100 Cartridge Bin - Handgun Recoil Spring Tester 2.0

The Next Generation of Diagnostics: Armanov Handgun Recoil Spring Tester
Troubleshooting handgun malfunctions can be a frustrating guessing game. With the upgraded Armanov Recoil Spring Tester, you can instantly isolate or eliminate one of the most common sources of reliability issues: a worn-out recoil spring. Featuring a simplistic, highly effective design, this tool makes verifying your spring weight fast, repeatable, and precise.



Attributes

- Name: Handgun Recoil Spring Tester 2.0
- Manufacturer: ARMANOV
- Product no.: EU2018659
- Mfr. No.: RSPRINGT2
- Colour: Black
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Armanov Handgun Recoil Spring Tester 2.0](#)

Safety Instruction Guide for Armanov Handgun Recoil Spring Tester 2.0

Introduction

Thank you for purchasing the Armanov Handgun Recoil Spring Tester 2.0. This product is designed to assist you in diagnosing handgun malfunctions related to recoil springs. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose as outlined in this guide.
- Always keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of damage or wear before use.
- If you notice any defects, do not use the product and contact the manufacturer for assistance.
- Follow all local laws and regulations regarding the use of firearms and related accessories.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) when testing recoil springs, including safety glasses.
- Make sure that the firearm is unloaded and safe before using the recoil spring tester.
- Do not use the recoil spring tester in a crowded or unsafe environment.
- Avoid using the tester near flammable materials or in wet conditions.
- Keep your hands and face clear of the tester's moving parts during operation.
- Do not modify or alter the recoil spring tester in any way.

Instructions for Installation and Usage

Installation

1. Unbox the Armanov Handgun Recoil Spring Tester 2.0 and ensure all parts are included.
2. Place the tester on a stable, flat surface to ensure proper operation.
3. If applicable, follow the manufacturer's instructions for any additional assembly.

Usage

1. Preparing the Firearm:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the recoil spring from the firearm as per the manufacturer's instructions.

2. Using the Tester:

- Insert the recoil spring into the designated area of the tester.
- Follow the onscreen or printed instructions to adjust the tester settings as needed.
- Activate the tester to measure the recoil spring weight.
- Record the results for further analysis.

3. PostUse Care:

- Carefully remove the recoil spring from the tester.
- Clean the tester according to the manufacturer's maintenance recommendations.
- Store the tester in a safe, dry place when not in use.

Disposal Instructions

- Dispose of the product in accordance with local regulations regarding electronic waste and nonfood products.
- Do not dispose of the product in regular household waste.
- If you are unsure about the disposal methods, consult your local waste management authority for guidance.

Contact Information for Further Support

For safety inquiries or further support regarding the Armanov Handgun Recoil Spring Tester 2.0, please refer to the manufacturer's website or customer service resources.

Please ensure that you follow these safety instructions to maximize your safety and the effectiveness of the Armanov Handgun Recoil Spring Tester 2.0. Thank you for your attention to these important guidelines.