

Small Pin for Armanov Swage PRO | Dillon XL650 / XL750 - Milled Aluminium Station One Locator for Dillon XL650/XL750 (#3 - 13614)

Eliminate the weak link in your progressive reloading cycle. Station One dictates the alignment of your entire progressive run, yet factory components often flex under heavy use, leading to tilted cases and jammed indexing. The Armanov Station One Locator # is precision CNC-machined from premium high-grade aluminium, delivering industrial rigidity to ensure every cartridge enters the cycle with absolute geometric perfection.



Attributes

- Name: Milled Aluminium Station One Locator for Dillon XL650/XL750 (#3 - 13614)
- Manufacturer: ARMANOV
- Product no.: EU2018687
- Mfr. No.: ST1LAL-3
- Colour: Silver
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Small Pin for Armanov Swage PRO | Dillon XL650 / XL750](#)

Safety Instruction Guide for Small Pin for Armanov Swage PRO | Dillon XL650 / XL750

Introduction

Thank you for choosing the Small Pin for Armanov Swage PRO. This guide provides essential safety instructions to ensure the safe and effective use of the product. Please read this document carefully before using the product to avoid any potential hazards.

General Safety Guidelines

- Ensure that the product is used in accordance with the manufacturer's instructions.
- Always inspect the product for any signs of damage before use.
- Keep the product out of reach of children and vulnerable individuals.
- Use the product only for its intended purpose as specified in this guide.
- If you notice any unusual performance or hear unusual noises during use, stop immediately and inspect the product.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when using this product.
- Avoid using the product in wet or damp conditions to prevent slipping or electrical hazards.
- Do not exceed the recommended load limits specified by the manufacturer.
- Ensure that all components are securely fastened before operating the equipment.
- Keep hands and loose clothing away from moving parts during operation.

Instructions for Installation and Usage

1. Installation:

- Ensure that the work area is clean and free of clutter.
- Locate the appropriate position for the Small Pin on your Dillon XL650/XL750.
- Align the Small Pin with the designated locator hole on the Station One.
- Gently insert the Small Pin into the locator hole, ensuring a snug fit.
- Secure the Small Pin in place as per the Dillon XL650/XL750 manual instructions.

2. Usage:

- Before starting the reloading process, doublecheck that the Small Pin is properly installed.
- Follow the standard operating procedures for your Dillon XL650/XL750.
- Monitor the operation closely for any signs of misalignment or instability.
- If misalignment occurs, stop the operation immediately, remove the Small Pin, and inspect for damage.

Disposal Instructions

- Dispose of the product in accordance with local regulations for metal recycling.
- Do not dispose of the product in household waste.
- Ensure that any sharp edges are safely managed to prevent injury during disposal.

Contact Information for Further Support

For any questions or concerns regarding the safety and usage of the Small Pin for Armanov Swage PRO, please contact the manufacturer directly or consult the relevant support channels.

Thank you for prioritizing safety and compliance while using your Small Pin for Armanov Swage PRO.