

Small Pin for Armanov Swage PRO | Dillon XL650 / XL750 - Milled Aluminium Station One Locator for Dillon XL650/XL750 (B - 13156)

Eliminate the weak link in your progressive reloading cycle. Station One dictates the alignment of your entire progressive run, yet factory components often flex under heavy use, leading to tilted cases and jammed indexing. The Armanov Station One Locator # is precision CNC-machined from premium high-grade aluminium, delivering industrial rigidity to ensure every cartridge enters the cycle with absolute geometric perfection.



Attributes

- Name: Milled Aluminium Station One Locator for Dillon XL650/XL750 (B - 13156)
- Manufacturer: ARMANOV
- Product no.: EU2018690
- Mfr. No.: ST1LAL-B
- Colour: Silver
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Small Pin for Armanov Swage PRO | Dillon XL650 / XL750](#)

Safety Instruction Guide for Small Pin for Armanov Swage PRO | Dillon XL650 / XL750

Introduction

Thank you for purchasing the Small Pin for Armanov Swage PRO designed for Dillon XL650 and XL750. This product is engineered to enhance the safety and efficiency of your progressive reloading cycle. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always follow the manufacturer's instructions for installation and use.
- Ensure that the product is used in accordance with its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe conditions or incidents related to the product to the appropriate authorities.

Specific Safety Precautions for Use

- Before using the Small Pin, ensure that your Dillon XL650 or XL750 is turned off and unplugged.
- Use protective eyewear and gloves when handling the product to prevent injury.
- Ensure that the work area is clean and free from obstructions to avoid accidents.
- Do not exceed the recommended load limits as specified in the user manual of your Dillon reloading machine.
- Avoid using the product if it appears damaged or if any components are missing.

Instructions for Installation and Usage

1. Installation:

- Ensure that the Dillon XL650 or XL750 is powered off and unplugged.
- Locate the Station One position on the reloading machine.
- Carefully insert the Small Pin into the designated slot, ensuring a snug fit.
- Doublecheck the alignment of the pin to ensure it is correctly positioned.

2. Usage:

- Once installed, power on the Dillon XL650 or XL750.
- Begin your reloading cycle, monitoring for any irregularities or issues.
- If you notice misalignment or jamming, immediately stop the machine and inspect the Small Pin and surrounding components.
- Regularly clean the area around the Small Pin to prevent debris buildup.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- If the product is damaged beyond repair, recycle materials where possible.
- Do not dispose of the product in household waste. Check for designated recycling centers.

Contact Information for Further Support

For safety inquiries or additional support regarding the Small Pin for Armanov Swage PRO, please refer to the

manufacturer's official website or contact their customer service department.

By following these safety instructions, you can ensure a safe and efficient experience with your Small Pin for Armanov Swage PRO. Thank you for prioritizing safety in your reloading activities.