

ALPHA TANK BRAKE - MIDWEST INDUSTRIES, INC. ALPHA TANK BRAKE - BLACK NITRIDE - 1/2X28-9MM

[Rifle Parts](#) > [Muzzle Devices](#) > [Compensators & Muzzle Brakes](#)

ALPHA TANK BRAKE FEATURES: Dual chamber brake for maximum reduction in muzzle climb Constructed from 416 Stainless Finish Options: Blast or Black Nitride Weight: 12 oz Diameter: 2.25" Diameter hole: .410 Made for thread pitch 24MM / M14X1LH / 1/2X28-9MM Made in the USA Lifetime Warranty



Attributes

- Name: [MIDWEST INDUSTRIES, INC. ALPHA TANK BRAKE - BLACK NITRIDE - 1/2X28-9MM](#)
- Manufacturer: [MIDWEST INDUSTRIES, INC.](#)
- Product no.: 430112429
- Mfr. No.: MI-ALPHA-TB1/2X28-9MM-N
- Finish: Black
- Material: Stainless Steel
- Threads: 1/2-28
- Weapon type: AK-47
- Delivery weight: 0.454kg
- Shipping height: 102mm
- Shipping width: 102mm
- Shipping length: 102mm
- UPC: 812102035527

Item details

Made in USA

Table of Contents

- [Startpage](#)
- [ALPHA TANK BRAKE Safety Instructions](#)
- [About Us](#)

ALPHA TANK BRAKE Safety Instructions

Introduction

Thank you for choosing the ALPHA TANK BRAKE manufactured by MIDWEST INDUSTRIES, INC. This guide provides important safety information and instructions for the proper use, installation, and disposal of the product, ensuring compliance with the EU General Product Safety Regulation (GPSR). Please read this document carefully before use.

General Safety Guidelines

- Ensure safe use of the ALPHA TANK BRAKE by following all instructions.
- Be aware of potential hazards associated with the product, including risks of injury during installation and use.
- Always handle the product with care to avoid accidents.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly check for updates on safety recalls via the EU's Safety Gate platform.
- Report any unsafe conditions or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling or installing the brake.
- Ensure that the firearm is unloaded and pointed in a safe direction before installation.
- Check the compatibility of the ALPHA TANK BRAKE with your firearm's specifications (thread pitch).
- Do not exceed the manufacturer's recommended weight limit when using the brake.
- Avoid using the product if it appears damaged or has been modified.
- Regularly inspect the brake for signs of wear or damage and replace it if necessary.

Instructions for Installation and Usage

1. Preparation

- Ensure your firearm is unloaded and in a safe condition.
- Gather necessary tools for installation, including a wrench suitable for the thread pitch.

2. Installation

- Locate the threaded muzzle of your firearm.
- Clean the threads to remove any debris or old thread sealant.
- Align the ALPHA TANK BRAKE with the threads and handtighten it onto the muzzle.
- Use the wrench to securely tighten the brake, ensuring it is firmly in place but do not overtighten to avoid damage.

3. Usage

- After installation, conduct a function check to ensure that the brake is properly installed and that the firearm operates correctly.
- When firing, maintain a safe distance from others and ensure the area is clear.
- Monitor the brake during use for any signs of loosening or damage.

Disposal Instructions

- Dispose of the ALPHA TANK BRAKE in accordance with local regulations for metal products.
- Do not dispose of the brake in regular household waste.
- If the product is damaged or no longer usable, consider recycling options available in your area.

Contact Information for Further Support

For assistance regarding the ALPHA TANK BRAKE, please refer to the manufacturer's contact details provided with the product packaging or visit their official website for further information.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk